

HÄFELE

**NAGOLD**  
APPLIANCES

## IMPORTANT SAFEGUARDS

When using this appliance, basic precautions should always be followed, including the following:

1. Read all instructions before using.
2. Do not operate the appliance with damaged power cord or plug, after the appliance malfunction, or if it is dropped or damaged in any manner. Return the appliance to the nearest authorized dealer or after-sales service center for examination, repair, electrical or mechanical adjustment.
3. Do not use the appliance if the plug, the mains cord or other parts are damaged.
4. Do not let the power cord hang over edge of table or counter or hot surface.
5. Do not place the appliance on or near hot gas or electric burner, or in a heated oven.
6. Do not leave the appliance unattended while operating.
7. Do not touch the cutting edges of the blender blade unit when you clean it. They are very sharp and you could easily cut your fingers on them.
8. Do not operate the appliance for more than 3 minutes continuously at a time. If you have not finished processing after 3 minutes, switch off the appliance and let it cool down before you operate it again.
9. To prevent failure of the appliance, make sure that no food or liquids enter the connection point between the blade unit interface and the motor base.
10. To prevent spillage, do not put more than 1.0 liters of liquid in the glass jar, especially when you process at a high speed.
11. Never reach into the glass blender with your fingers or an object while the appliance is running.
12. Never use any accessories or parts from other manufacturers or that HEMILTON does not specifically recommend.
13. Oversized foods or metal utensils must not be inserted into the glass jar as they may cause fire or risk of electric shock.
14. If foods stick to the wall of the glass jar, switch off the appliance and unplug it. Use a spatula to remove the foods from the wall.
15. Always make sure the jar cover is properly closed/assembled on the glass jar and the lid is inserted properly in the jar cover before you switch on the appliance.
16. **Never immerse motor base in water or any other liquids nor rinse it under the tap. Use only a moist cloth to clean the motor base.**
17. Close supervision is necessary when your appliance is being used near children or infirm persons.
18. Always unplug the appliance before you assemble, disassemble or make adjustment to any parts of the blender.
19. Do not operate the appliance for other than its intended use.
20. Do not use this blender outdoors.
21. This appliance is for domestic use only.
22. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
23. Children should be supervised to ensure that they do not play with the appliance.
24. Save these instructions for future reference.

## PRODUCT DESCRIPTION



1. Base unit
2. Micro safety switch
3. Lower connector
4. Control panel
5. Feet
6. Power cord with plug
7. Glass jar
8. Spout
9. Jar handle
10. Jar base
11. Blade assy
12. Sealing ring
13. Inner lid
14. Jar cover
15. Cover gasket
16. Assembling aid tool
17. Grinder mill

## BUILT-IN SAFETY LOCK


This feature ensures that you can only switch on the appliance if you have properly assembled the glass jar on the motor base. When the glass jar is correctly assembled on the motor base, the jar seating will push the built-in safety lock on the motor base and the safety lock be unlock.

**\* When moving or handling the blender, the whole unit cannot be tilted in order to prevent the glass jar from falling down.**

## ASSEMBLE AND OPERATING THE APPLIANCE

1. Unpack the appliance and place it on a flat horizontal counter top. Check all the parts whether all in good condition.
2. Clean the removable parts before using.
3. Make sure that the control knob is switched to “OFF” position.
4. Put the ingredients into the glass blender.
5. Mount the lid onto the jar cover. Close the glass jar with jar cover.
6. Insert the glass jar onto the motor base and secure it tightly.
7. Power on the appliance and select the desired power level or press the quick-select button.
8. Always switch off the appliance by setting the control knob to “OFF” position before you open the jar cover.
9. Unplug the plug from wall outlet after use.

## CONTROL KNOB AND BUTTONS

Control knob and buttons	Description
	<ul style="list-style-type: none"> <li>➤ This blender is equipped with illuminated ring that lights up when it is connected to power.</li> <li>➤ You can set the control knob to any speed from min to max level or, even easier, use one of three quick-select buttons: smoothie, auto-clean and ice-crush.</li> </ul>
<p>To use a quick-select button</p>	<ul style="list-style-type: none"> <li>➤ If you want to use the quick-select button, first turn the control knob to position to ON. Then press desired quick-select button.</li> </ul>
<p>Smoothie function</p>	<ul style="list-style-type: none"> <li>➤ Use this function to prepare delicious smoothies. For example, fruit and yogurt or fruit and milk based drinks; fruit or vegetable drinks.</li> <li>➤ When you press this button, the appliance starts mixing the ingredients according to the appropriate speed profile.</li> <li>➤ To stop the process, press the smoothie button again.</li> </ul>

Auto-clean function	<ul style="list-style-type: none"> <li>➤ Empty the glass jar and fill it with water.</li> <li>➤ Place the glass jar on the motor base and pressed the auto-clean button.</li> <li>➤ Empty the glass jar and rinse until clean.</li> </ul>
Ice-crush function	<ul style="list-style-type: none"> <li>➤ When you press the ice-crush button, the appliance starts crushing the ice according to the appropriate speed profile.</li> <li>➤ To stop the ice-crushing process, press the ice-crush button again. The ice will be crushed within few seconds and the result is tiny, regular pieces of ice.</li> </ul>

## How to use the grinder mill

1. Place the dry foodstuff like coffee beans, almonds, peanuts, nuts and more into the grinder base.
2. Put the grinder cover on the grinder base and close securely.
3. Press the grinder mill cover by hand and switch on the motor base to mill.
4. Please always use Min. - Max. speed knob to operate with grinder mill.
5. Grinder mill working time: maximum 20 seconds working and stop 10 minutes as a cycle, after 3 cycles working, need to let the machine cool down completely (rest time >30minutes).


## TIPS

- To achieve the best results when pureeing solid ingredients, place small portions into the glass jar one by one instead of placing a large quantity all at once.
- If you are processing solid ingredients, cut them into small pieces (2-3cm) first before putting them into the glass jar.
- When mixing solid ingredients start off first with a small amount of liquid. Gradually add more and more liquid through the opening in the jar cover.
- Always place your hand on top of the blender when you operating the appliance.
- Do not operate the appliance for more than 3 minutes continuously at a time. If you have not finished processing after 3 minutes, switch off the appliance and let it cool down before you operate it again.
- Grill mill: max. working time 20seconds and stop at least 10 minutes.

## Dismounting the blade unit from the glass jar

- Turn the jar upside down and place it on a level non-slip surface
- For dismounting the blade unit,

1) use the enclosed assembling aid tool



- Put on the assembling aid tool.
- Hold the glass jar with one hand; turn the assembling aid tool anticlockwise to the stop with the other hand in order to loosen the blade unit.

2) use the cover as a tool for loosening the blade unit.



- Inside the cover there are 2 detents, which are put into the notches at the blade unit.
- Hold the glass jar with one hand, turn the cover anticlockwise to the stop with the other hand in order to loosen the blade unit.

- Now grip the blade unit and cautiously lift it to the top.
- Remove the rubber gasket.



## CLEANING AND MAINTENANCE

1. Unplug the appliance.
2. Disassemble all removable parts before cleaning.  
**Note: Do not rinse the motor base under water tap. Do not use abrasive cleaning agents, sources, etc. to clean the motor base!**
3. When cleaning the glass jar, be careful of the blades as it is very sharp.
4. Clean the motor base with a moist cloth.
5. Clean the removable parts immediately after use.

## SPECIFICATIONS

1. Voltage : 220V-240V, 50/60Hz

2. Power :1200W

3. Short time operation:

- Glass jar: maximum 3 minutes and stop 1 minute, operate 10 times and need to let the appliance cool down at least 30 minutes.
- Grinder mill: maximum 20 seconds working and stop 10 minutes as a cycle, after 3 cycles working, need to let the machine cool down completely (rest time >30minutes).

## Environment friendly disposal



You can help protect the environment!

Please remember to respect the local regulations: hand in the non-working electrical equipments to an appropriate waste disposal center.

# H'AFELE

**Mumbai Corporate Office:**

Office No. 3, Building "A", BETA,  
I Think Techno Campus, Off J.V.L.R,  
Opp. Kanjurmarg East, Mumbai - 400 042.  
Tel.: 022 6142 6100 • Fax: 022 6702 0531.

**For Enquiries SMS "HAFELE" to 56070**  
Toll Free Customer Care: 1800 266 6667  
customer@hafeleindia.com  
info@hafeleindia.com



<http://facebook.com/hafeleindia>



<http://www.twitter.com/hafeleindia>

